



SPARE PARTS LIST

BJÖRK waste bin 18 l

3320/3325/3330



| Pos. No. | Art. No. | Spare part |
|----------|----------|--|
| 5 | 28208 | Complete lock mechanism excl. key (silver) |
| | 28209 | Complete lock mechanism excl. key (black) |
| 7 | 28202 | Square key, black, polyamide |
| 9 | 33200 | Front cover |
| 10 | 33205 | Back plate |
| 11 | 33210 | Ring holder for plastic bag |